



# Model CK3800 CCD Video Camera Pin Outs and Control Settings

## CONTROLS




SHUTTER SPEED MODE



WHITE BALANCE MODE


## PIN CONNECTIONS

### LENS PLUG



1. +12VDC output
2. Video output
3. Ground
4. No connection

### POWER PLUG



1. VD signal input
2. HD signal input
3. Ground
4. Ground
5. No connection
6. +12VDC input