

Instruction Manual for MG750 Series Magnifier Lamp

Thank you for purchasing our Magnifier Lamp, MG750 Series. The unit is ideal for precise work in home, office, workshop as well as a lot of other important places. Before using the MG750 Series, please read the following instructions:

Parameter:

- 1) Lens size: 7.5"X6.2"
- 2) Lens: 3D
- 3) Magnification: 1.75X
- 4) Voltage: 110v 60Hz
- 5) Power: 12w (60pcs LED)
- 6) Working Distance: 9 inches (228.6mm)

How to use:

Clamp the bracket to the edge of the horizontal surface which you have chosen. Insert the bottom stem of the arm into the hole in the bracket. Plug in the magnifier lamp.

Important for safe use:

- 1) Indoor use only.
- 2) Environment temperature $-5^{\circ}\text{C}\sim 40^{\circ}\text{C}$.
- 3) Humidity: $\leq 95\%$.
- 4) Never disassemble the magnifier lamp unless you are a qualified electrician.
- 5) Plug must be taken out while repairing the magnifier lamp.